

CC-Dr. Schutz GmbH

Steinbrinksweg 30
D-31840
Hessisch Oldendorf
Fax: +49-(0)5152-9779-30
Tel: +49-(0) 5152-9779-0
info@dr-schutz.com
www.dr-schutz.com

Dr. Schutz UK Ltd.
Unit 24, Anglo Business Park
Smeaton close Aylesbury Bucks HP19 8UP
Great Britain
Fax: 01296-334 219
Tel: 01296-437 827
steve@dr-schutz.com
www.dr-schutz.com

Product-Information

Click Sealer

1. Product Description

A high quality impregnation of the edges of laminate and sealed wood and cork floors. Reduces the risk of surface swelling caused by dampness at the edges.

2. Areas of Application

EN 13329-defined laminate floor coverings and sealed wood floors. For floorings with a surface of paper-décor the application may be reduced due to a possible colour change. Therefore, it is recommended to previously test on a sample.

3. Method of Application

Shake Click Sealer well before use. Then spread it thinly onto the dry floor and work it into the seams using a spatula made of plastic or high-grade steel-flex. Thoroughly remove the excessive impregnation material with the spatula. Then polish the surface with a soft non-fraying cloth or the SRP1 monodisc with a white pad until a uniform sheen is achieved. To avoid Click Sealer from drying too soon, always treat only small sections. After finishing leave to dry polished surface overnight before you walk on the floor again. Footsteps that may occur after drying can be equalised by polishing with a smooth brush.

Consumption: 250 ml = 40 m²

Note: While drying, due to contact with oxygen in the air, the used cloths or pads could self-ignite in case of heat deceleration. Therefore leave used cloths or pads spread out or keep them in water or locked up in containers. Ensure sufficient air during and after application of product. Do not inhale product fumes. If Click Sealer has been swallowed, do not induce vomiting. Immediately seek a doctor and show label or product information.

4. Technical Data

pH level: cannot be determined, product is solvent based
Product code for cleaning and care products (Giscode): GH 10

Data on ingredients (EC recommendation): natural oils and waxes, aliphatic hydrocarbons, unleaded dry substances.

Click Sealer should be stored in a cool, dry place in its closed original container. Protect from frost. Keep locked up and out of the reach of children.

Click Sealer

Only feed completely empty canisters into recycling systems. Rinsing out reduces costs and protects the environment!

5. Unit Sizes

8 x 250 ml

Art.-No. 2260025016

www.dr-schutz.com

The above advice on procedure for use is based on the best of our knowledge and the latest information available on cleaning technology. For this reason, when using our quality products, no damage will be incurred to the materials to be cleaned if strict attention is paid to the instructions printed on the container and the procedure suggested by us is followed. The use to which our products are put is, however, beyond our control. It is the responsibility of the user and does not release the user from making his own checks of the products supplied by us as to their suitability for the intended procedure and purposes. The information supplied by us is therefore non-binding and cannot be used as a basis for establishing the company's liability for any damage incurred. This also includes the infringement of any rights for the protection of third parties.

